CUTEK®
WOOD STRIPPER

PROFESSIONAL WOOD AND SURFACE COATING STRIPPER



BENEFITS

- **Powerful wood stripper** – removes old surface coatings from wood, metal, brick and masonry surfaces
- **Smart alternative** – does not use dangerous chemicals like Methylene Chloride and NMP
- **Safe and user-friendly** – safe to use on your DIY project; no professional experience necessary

USES

CUTEK® Wood Stripper (formerly CUTEK® CD33 Naked) is a powerful and user-friendly paint and surface coating stripper. CUTEK® Wood Stripper is DIY-friendly; no professional experience is necessary.

CUTEK® Wood Stripper is suitable for removing multiple layers of the most commonly used wood coatings such as latex paints, stains, varnishes, linseed oils, acrylics and other film forming coatings. It is also effective at removing coatings from metal, brick and masonry surfaces.

Powerful yet safe, CUTEK® Wood Stripper is the smart alternative to conventional strippers that use dangerous chemicals (such as methylene chloride, NMP, etc.).

SPECIFICATIONS

TYPICAL PROPERTIES AND APPLICATION DATA

CLASSIFICATION	Paint stripper
COMPONENTS	One
FLASH POINT	> 100°C (212°F)
pH	8 as supplied
THINNER	Do not thin
PACK SIZES	3.78L (1 US gal)

COVERAGE

Spreading rate is approximately 3 m^2/L (120 ft^2/gal)

Note: this can vary significantly depending on the type and thickness of the paint or wood coating being removed.

CUTEK® WOOD STRIPPER



PREPARATION AND PROTECTION GUIDELINE

This is a guide only and not to be used as a specification. Contact CUTEK® to discuss your specific project requirements.

WOOD CONDITION/ DESIRED EFFECT	SITUATION	PREPARATION	PROTECTION	ADD CUTEK® COLOURTONE? (Y/N)
OLD WOOD - **Previously coated with film forming coating** Retain freshly oiled look or alter the wood colour	Exterior	Remove previous coating with CUTEK® Wood Stripper then clean with CUTEK® Wood Reviver	Apply 2 coats of CUTEK® Extreme	Y
OLD WOOD - **Previously coated with film forming coating** Stabilize & allow to naturally lighten/silver	Exterior	Remove previous coating with CUTEK® Wood Stripper then clean with CUTEK® Wood Reviver	Apply 2 coats of CUTEK® Extreme	N

CUTEK® WOOD STRIPPER



DIRECTIONS FOR USE

APPLICATION

APPLICATION PRECAUTIONS	**Before you get started:** Note the hazards and precautions on the CUTEK® website and the container labelling, and ensure that you use the correct safety equipment as detailed in the Safety Data Sheet. It is also important to be aware of the potential for wind drift into areas with cars or pedestrian traffic when rinsing. Water flush all equipment, vegetation, paths, concrete, asphalt and other adjacent surfaces before and after contact. A full list of application precautions is available on our website at www.cutekstain.com or by checking with customer service on 1-844-442-8835. DO NOT SWALLOW. CUTEK® Wood Stripper will make surfaces slippery, DO NOT walk on the surface until CUTEK® Wood Stripper has been removed. Leave job site free of any trace amounts of CUTEK® Wood Stripper. Never leave behind any containers or equipment and appropriately label any containers of residual for disposal.
STEP BY STEP APPLICATION PROCESS	Apply CUTEK® Wood Stripper evenly with a brush, roller or paint pad to dry wood, rubbing into the grain. Reaction time is approx. 30-60 minutes. Keep area wet and activated by applying more CUTEK® Wood Stripper or by agitating the application area with a brush, roller or paint pad. Test periodically with a paint scraper to determine when the old coating is stripping cleanly off the wood. When this happens, the stripped surface is ready for rinsing. We suggest that you try to strip only 1 square metre (≈10 ft^2) first to perfect your technique. Once CUTEK® Wood Stripper has loosened the coating, it must be power rinsed off thoroughly. For best results, use a pressure washer set to approximately 50 bar (750 p.s.i.) with a fan jet pattern. Keep an operating distance of at least 4" from the wood. REMOVAL WITH A GARDEN HOSE IS NOT SUFFICIENT. CAUTION must be used to avoid damage to the wood fiber and 'furring up'. Adjust your cleaning process by reducing the pressure or your operating distance from the wood. DO NOT use "turbojets" on wood. Clean from the lowest point and work upwards methodically using long even strokes in the direction of the grain. If cleaned from the highest point first, the product below can become sticky and difficult to remove. After stripping the wood, clean your wood with CUTEK® Wood Reviver to remove residual CUTEK® Wood Stripper and rejuvenate the substrate. Certain types of wood surfaces may leave a raised grain effect after stripping is completed. Sanding or poly pad scrubbing may be required to smooth out this condition. **Clean-up:** Equipment may be cleaned with CUTEK® Quickclean or soap/detergent and water. All wash water, containers/contents should be disposed in accordance with local regulations.

CUTEK® WOOD STRIPPER



IMPORTANT INFORMATION

CUTEK® Wood Stripper is a powerful and user-friendly paint/surface coating stripper. It is suitable for removing multiple layers of the most commonly used wood coatings such as latex paints, stains, varnishes, linseed oils, acrylics and other film forming coatings. It is also effective at removing coatings from metal, brick and masonry surfaces. Powerful yet safe, CUTEK® Wood Stripper is considered the smart alternative to conventional strippers that use dangerous chemicals (such as methylene chloride, NMP, etc.)

It is important for the user to determine the suitability of CUTEK® Wood Stripper for your intended application. ALWAYS test product on a small test area. The coatings to be stripped can vary significantly, testing will enable you to accurately estimate the working time, and amount of CUTEK® Wood Stripper required to complete your project. It will also enable you to perfect the technique that works best for your situation.

Note: CUTEK® Wood Stripper may need to be applied more than once to thick paint or film form coatings with many layers.

STORAGE & SAFETY

SAFETY	**Read Safety Data Sheet and any precautions on container label.**
STORAGE	This product is NOT classified as dangerous goods for transport or storage in Canada. Store in well ventilated bunded area under cover and away from sources of heat. Keep containers closed at all times.
HANDLING	As with any chemical, ingestion, inhalation or contact with eyes and skin should be avoided by good occupational work practice. Eye protection approved to CAN/CSA Z94.3-15 and impervious rubber gloves should be worn where there is a risk of splashes entering the eyes or contacting the skin. Always wash hands before smoking, eating, drinking or using the toilet.
USING	Use with good ventilation and avoid inhalation of spray mists and fumes. If risk of inhalation of spray mists exists, wear combined organic vapour/particulate respirator.
FLAMMABILITY	This product is a combustible liquid. On burning may emit toxic fumes.

CANADIAN LICENSE HOLDER

Deck Source Inc.
22 Winstar Rd, Unit 1
Oro-Medonte, ON, L0L 2L0

Contact:
1-844-442-8835

The data presented in this medium and any advice, recommendation, information, assistance or service provided by CUTEK® in relation to goods manufactured by it or their use and application is given in good faith and is believed by CUTEK® to be appropriate and reliable. However, any advice, recommendation, information, assistance or service provided by CUTEK® does not absolve the user from carefully checking all supplies immediately on receipt. We reserve the right to alter product constants within the scope of technical progress or new developments. The recommendations made in this medium should be checked by preliminary trials because of conditions during processing over which we have no control, especially where other companies' raw materials are also being used. The information provided by us does not absolve the user from determining suitability of the product for their own purpose. Recommendations for use do not constitute a warranty, either express or implied, of the fitness or suitability of the product for a particular purpose.